



Orientation rib



Connector
BJB / B+W 35mm-interface



Screw holes:
● HEKLA SOCKET-B-35
● Others
 Screw hole positions to be checked per socket/connector

INDEX	PART	TYPE	QTY	MATERIAL	COLOUR/COATING	ASSEMBLY CODES
1	AMY-35-0	LENS	1			
	C18491_ AMY-35-0			PMMA	CLEAR	
2	HOLDER B	HOLDER	1			
	C19996_ AMY-35-HLD2-B-ASYM-0			PC	BLACK	CP19165_ AMY-35-0-B2
	C19999_ AMY-35-HLD2-B-WHT-ASYM-0			PC	WHITE	CP19171_ AMY-35-0-B2-WHT

MECHANICAL DRAWING		LEDiL
PRODUCT AMY-35-0		
Plastic moulding general tolerances according to DIN 16901-130 and applies if not otherwise shown in the drawing. Silicone moulding general tolerances according to ISO 3302-1 Class M3 and applies if not otherwise shown in the drawing.	FIRST ANGLE PROJECTION: 	This drawing is the property of LEDiL Oy. It may not be copied or otherwise distributed without prior written permission from LEDiL Oy.
SCALE 2:1	WEIGHT -	A3 SHEET 1/2



Notes

●	PCB or heatsink level.
●	LED location
	Ensure LED fitting from a product specific 3D model available from www.ledil.com
	For more details about installation please see LEDiL Installation Guide on www.ledil.com

H G F E D C B A

4

4





3

3

Orientation rib

Beam direction



2

2

PART	TYPE	MATERIAL	COLOR / COATING
C18491_AMY-35-0	LENS	PMMA	CLEAR


MECHANICAL DRAWING

PRODUCT **AMY-35-0**

LEDiL

Plastic moulding general tolerances according to DIN 16901-130 and applies if not otherwise shown in the drawing. Silicone moulding general tolerances according to ISO 3302-1 Class M3 and applies if not otherwise shown in the drawing.

FIRST ANGLE PROJECTION:



This drawing is the property of LEDiL Oy. It may not be copied or otherwise distributed without prior written permission from LEDiL Oy.

SCALE 2:1

WEIGHT -

A3 SHEET 2/2

1

1

Notes

	PCB or heatsink level.
	LED location
	Ensure LED fitting from a product specific 3D model available from www.ledil.com
	For more details about installation please see LEDiL Installation Guide on www.ledil.com

H G F E D C B A